

MR CHOMPS USER GUIDE




	Sizing	Inside Width	Weight (pair)
Regular	boards 26cm waist or less	13.8cm	14oz
Wide	boards over 26cm waist	14.8cm	14.4oz



Before use

Shims are shipped with your new crampons. Swap these with the Voile pin guides underneath the touring brackets. Mr. Chomps will then grab onto the underside of the touring pin as shown here.



For questions or concerns / 406.580.7674 or sales@sparkrandd.com



To install your crampons, rotate the bindings forward and hook the crampon underneath the touring pin.

IMPORTANT: Make sure the crampon is fully engaged on the pin. Failure to do so can result in damaged or lost crampons.



When the skin track is steeper, flip up the heel rests on your board and Mr. Chomps. For ease of skinning, the crampon will float over the snow on your forward stride and dig in when you weight your heels. Remember, for maximum grip from your skins and crampons, stand up straight and keep weight on your heels. Weighting your toes and leaning forward will increase your chance of slipping.

